

Figure 1

Sidecar Mounts BMW - K1200 LT

1. Remove right side center fairing plastic with the blinker light.
2. Remove rear upper plastic above rear floor boards
3. Remove lower front fairing plastic
4. Remove the plastic panel above and around drivers foot peg
5. Remove the seat



Upper Front Sub Frame

1. Using the original bolt with the lock washer and flat washer supplied attach the upper front sub frame as shown in Fig 1 # 1

Figure 2

Attach the upper front sub frame to the lower sub frame Fig 2 # 2 using the 3/8" x 1 1/4" hhcs, nylock nut and 2 flat washers



Figure 3

Upper Rear Mount (Eye Clamp)

Remove the seat and attach the eye clamp assembly to the frame rail as shown in Fig 3



Figure 4

Lower Rear Sub Frame

Figure 4 #1 is showing the upper rear mounting location of the lower rear sub frame using the 10mm x 1.50 x 45mm + lock washer and flat washer supplied by Champion



Figure 5

Lower Rear Sub Frame

Figure 5 #1 and 2 is showing the underside mounting location of the lower rear sub frame using the 10mm x 40 mm sh cs , lock washer and flat washer supplied by Champion.



steering damper bracket 2 10mm x 40mm 1.5mm pitch

Lower Front Sub Frame

Using the 2 , 8mm x 1.50mm x 25mm sh cs + lock washer and flat washer used on the outside and 2, 8mm x 1.50 x 25mm hhcs + lock washer and flat washers used on the inside mount the lower front sub frame to the engine location shown in Figure 6,# 1 and 2. Take note that there are two additional mounting locations for this mount at the opposite side of the motor.

Figure 6



IMPORTANT

It will be necessary to modify the upper cosmetic plastic panels of the motorcycle as necessary to allow clearance of the mounting eyes.

