

Harley Davidson Sportster 883/1200

UF- Strap clamp as high as possible on front down tube. Remove reflector from frame and install clamp.

LF- Remove four bolts holding front engine mount plates to frame. Disconnect wire from oil pressure sensor. Install mount between eng mount plates. Route wires in front of mount. Route or press wire through hole in center of right eng mount plate and behind sidecar mount.

UR- Strap clamp as high as possible on frame tube ahead or rear shock.

LR- Remove lower muffler bracket.
Install mount on motorcycle between exhaust bracket and frame with one new bolt provided and one stock bolt.