

1998 HONDA 750 SHADOW ACE (MOUNTING INSTRUCTIONS)

1. UPPER REAR

Place motorcycle on sidestand position a floor jack under the square frame tube just behind the engine and raise slowly until the rear shocks have extended to their limit but do not raise the rear wheel off the ground. Loosen (Do Not Remove) the lower shock bolt two or three turns. Remove the top shock bolt. Pull the top of the shock off of the mount stud and pivot the shock back to clear the stud. Remove the stud. Place the mount over the hole in front of the chrome fender brace and in front of the rear peg arm. Insert the shock stud mount and tighten using the 3/8" hole in the bottom of the mount as a guide drill a 3/8" hole through the rear peg arm. Insert the 3/8"x 16 x 1" bolt with washers and nylock nut. Tighten both ends. Now reinstall the shock.

2. LOWER MOUNT

Remove the lower exhaust support bolt. Install the U clamp over the lower frame rail just ahead of the rear brake lever return spring mount. Install the U clamp over the lower frame rail behind the front foot peg mount. Now install the lower mount to U clamps using 3/8"x24 x2" grade 8 bolts using lock washers and flat washers. Install one of the new bolts through the mount, rear tab and exhaust support lower hole and tighten the U bolts.

3. UPPER FRONT (small eye clamp)

Place the eye clamp as high as possible on the vertical frame tube behind the radiator. Tighten the eye clamp as tight as possible without crushing the frame rail while still having enough tightening movement to align the eye bolt from the eye clamp to the strut eye bolt. Do Not Loosen The Eye Clamp.