

## 99-2000 Indian Chief

Photo showing the positioning of the rear sub frame and the bolting locations.

#1 Rear mount to rear fender rail using the 3/8 x 16 x 1 3/4 hhsc and flat washer and lock washer.

#2 Locate and mount to this location using the 5/16 x 1" hhsc bolt flat washer and lock washer supplied.



This photo is showing the center and lower sections of the rear sub frame and the bolting locations.

# 1 & # 2 Using the 3/8 x 3 1/4 hhsc bolts flat washers and lock washers mount the lower rear sub frame to the motorcycle frame



**(2002 Chief rear mount)**



This photo is showing the bolt location located behind the muffler. Mount the rear sub frame to this location using the 5/16 x 1" hhsc flat washer and lock washer supplied.



### Upper Front

(Fig 3)

#### Eye Clamp Assembly

Install the strap clamp (figure 2) as high as possible on the right side vertical frame tube (figure 3). It is advisable to only hand tighten the eye bolt at this time.

**Note:** Be sure to install the two 1/4 bolts from the rear with the nuts facing forward to allow sufficient clearance between the bolt heads and the engine.

Remember the engine moves when it is running and if the clamp bolts are too close it could damage the head finish.



(2002 Chief upper front)



### Lower Front (2000 to 2002)

Remove the two front motor mount bolts. Insert the two 7 1/2" bolts with flat washers through the lower front mount from the bottom and install the mount on the motorcycle.

Be sure to retain the two stock flat washers under the nuts. Do not tighten until you have installed the strap U clamp over the frame at the rear of the mount. Now tighten the bolts.



## **Steering Damper (2000 to 2002)**