

INSTRUCTIONS
KAWASAKI VULCAN 800 CLASSIC AND DRIFTER

UPPER REAR

Remove the two bolts attaching the right side of the rear fender rail extension to the motorcycle frame. Attach the upper rear mount to this position using the two hex bolts, lock washers and flat washers supplied.

UPPER FRONT

Remove the two hex head frame bolts just above and ahead of the front exhaust. Install the mount with the eye at the top using the two 10mm x 1.25 x 70mm bolts and lock washers supplied.

LOWER SUBFRAME

Remove the two hex head bolts holding the front muffler to the motorcycle frame. Remove the two hex head bolts holding the front right footpeg and brake assembly plate to the frame. Remove the front left footpeg plate front mounting bolt. Install the subframe using the two 8mm x 1.25 x 35mm bolts and lock washers to replace muffler mount bolts. Use stock bolts for the front footpeg mounts to attach the subframe at the front.

Wheel lead use. 9" to 10"

Width use 14.50" minimum between inner frame tube on sidecar and subframe on the motorcycle to accommodate steering damper if necessary.

Steering Damper - Use 2" clamp to fork tube just below reflector

UPPER FRONT

UPPER REAR



LOWER SUB FRAME

STEERING DAMPER CLAMP

**LOWER SUB FRAME
FORWARD MOUNTING POSITION**



LOWER SUB FRAME (LEFT SIDE)

