

Photo showing position of the upper front eye clamp mount to the motorcycle frame.



Photo showing the position and bolting location of the lower front mount to the motorcycle frame.

- #1 Use the 10mm 1.5 x 80mm hhcs spacer and flat washer
- # 2 Use the 10 mm x 125 x 70 mm hhcs and flat washer and nylock nut



Photo showing the position and bolting location of the lower sub frame to the motorcycle frame. Use the 10mm x125 x 70mm hhcs and flat washer and nylock nut.



Photo showing mounting position of rear sub frame to the front bolt location of the right fender rail. Use the 8mm x 125 x 35mm hhsc x flat washer and lock washer. #1



Photo showing the lower front mounting position of rear sub frame to the motorcycle frame. Use the 8mm x 125 x 25mm hhcs and flat washer and nylock nut



Photo showing the lower rear mounting position of the rear sub frame to the motorcycle frame. Use the 8mm x 125 x 25mm hhcs and flat washer and nylock nut supplied



STEERING DAMPER- Use the two 3/8 x 2 1/4 hhcs , 2 flat washer and nylock nuts

